

Installation: Drill starter hole in desired place on floor. Screw door stop into floor. Position so that door will stop against rubber bumper. For an additional 1/4" height on the door stop when using with doors with a high clearance, or when the door stop is inset into the floor, use with Onward 1/4" riser (part #21855).

Use: To protect walls from swing of door.

Installation : Percer un trou pilote à l'emplacement désiré sur le plancher. Visser le butoir de porte dans le plancher. Poser de telle façon que la porte s'arrête contre le butoir en caoutchouc. Pour ajouter 1/4" (6 mm) à la hauteur du butoir lorsqu'il est encastré dans le plancher ou lorsqu'il est utilisé avec une porte à grand dégagement, utiliser la base de 1/4" (6 mm) de Onward (item #21855)

Utilisation : Pour protéger le mur lors de l'ouverture d'une porte.

Instalación: Perfore un agujero pequeño en la posición deseada del piso. Atornille el tope de puerta al piso. Posicione de manera que la puerta pege contra el paragolpes de goma. Para añadir 1/4 " (6 mm) a la altura de la parada cuando se encaja en el piso o cuando se utiliza con una puerta grande, utilizar la base de 1/4 " (6 mm) de Onward (item #21855)

Usage: Para parar las puertas y proteger paredes.